


# XNX™ Universal Transmitter



## Safety Manual

- Table of Contents
- SIL 2 Certificates
- Overview
- Safety Parameters
- Fault Diagnostic Time Interval
- Proof Test
- Proof Testing Procedure



**Table of Contents**

- 1 SIL 2 Certificate ..... 3
  - 1.1 XNX Gas Detector Transmitter..... 3
- 2 Overview..... 4
- 3 Safety Parameters ..... 5
  - 3.1 Interval of Proof Testing ..... 6
- 4 Fault Diagnostic Time Interval ..... 6
- 5 Proof Test..... 7
  - 5.1 Purpose of Proof Testing ..... 7
  - 5.2 Expected Outcome of Proof Testing ..... 7
  - 5.3 Tolerance of Output Current Levels ..... 7
- 6 Proof Testing Procedure ..... 7
  - 6.1 Checking..... 7
    - 6.1.1 Force mA Output ..... 7
    - 6.1.2 Zero Gas mA Output..... 8
    - 6.1.3 Calibration Gas mA Output..... 8
  - 6.2 Adjusting..... 8
    - 6.2.1 Calibrate 4.0 mA and 20.0 mA..... 8
    - 6.2.2 Zero Gas Calibration and Span Calibration ..... 8
      - 6.2.2.1 Zero Gas Calibration..... 9
      - 6.2.2.2 Span Calibration ..... 9
  - 6.3 Verifying mA Settings..... 10
  - 6.4 Testing ..... 11
    - 6.4.1 Fault and Alarm State ..... 11
    - 6.4.2 Gas Verification..... 12

## 1 SIL 2 Certificate

### 1.1 XNX Gas Detector Transmitter

**Certificate**




Functional Safety Type Approved  
www.tuv.com  
ID 060000000

**No.: 968/EZ 319.05/15**

<b>Product tested</b>	Gas Detector Transmitter XNX	<b>Certificate holder</b>	Honeywell Analytics Inc. 405 Barclay Boulevard Lincolnshire, IL 60069 USA
<b>Type designation</b>	XNX-ABCD-EFGGG A=Approval (A, U) B=Entry Type (M, T) C=Material (A, S) D=Personality (E, I, V) E=Option (N, R, M, F) F=Local HART (N, H) GGG=Sensor Range (NNN, CB1, IF1, IV1, IC1)		
<b>Codes and standards</b>	IEC 61508 Parts 1-7:2010		
<b>Intended application</b>	The XNX Gas Detector transmitter is suitable for safety related applications up to SIL 2 (IEC 61508).		
<b>Specific requirements</b>	For the use of the Gas Detector transmitter devices the installation instruction (released by Honeywell Analytics Inc), including recommendations for risk assessment and requirements for maintenance shall be considered.		
<b>Valid until</b>	2020-04-15		

The issue of this certificate is based upon an examination, whose results are documented in Report No. 968/EZ 319.05/15 dated 2015-04-15.  
This certificate is valid only for products which are identical with the product tested. It becomes invalid at any change of the codes and standards forming the basis of testing for the intended application.

**TÜV Rheinland Industrie Service GmbH**  
Bereich Automation  
Funktionale Sicherheit  
Am Grauen Stein, 51105 Köln  
Köln, 2015-04-15  
Certification Body for FS-Products



Dipl.-Ing. Heinz Gall

TÜV Rheinland Industrie Service GmbH, Am Grauen Stein, 51105 Köln / Germany  
Tel.: +49 221 890-1190, Fax: +49 221 890-1338, E-Mail: [institute.service@tuv.com](mailto:institute.service@tuv.com)

www.fs-products.com  
www.tuv.com

 **TÜVRheinland®**  
Precisely Right.

## 2 Overview

IEC 61508 is a generic functional safety standard. Functional safety is defined in this standard as “part of the overall safety relating to the Equipment Under Control (EUC) and the EUC control system which depends on the correct functioning of the E/E/PES<sup>1</sup> safety related systems, other technology safety-related systems, and external risk reduction facilities.”

A system is considered to be functionally safe if the random and systematic faults do not kill or injure humans, pollute the environment, and do not result in the loss of equipment or production.

A systematic fault is defined as a failure with a definite cause. A random fault can happen at any time and the cause is unclear. The terms fault and failure can be used interchangeably.

A Safety Integrity Level-certified system can detect the majority of safe and unsafe failures. XNX is SIL 2 capable per IEC 61508. XNX is SIL 3 capable in a redundant system per IEC 61508. [Table 1](#) and [Table 2](#) below outline a system’s safety integrity level in relation to its average probability of failure to perform its design function on demand and probability of dangerous failure per hour.

Table 1. Average Probability of Failure to Perform Its Design Function on Demand (Low Demand System)

Safety Integrity Level	Low demand mode of operation (Average probability of failure to perform its design function on demand (PFD))
4	$\geq 10^{-5}$ to $< 10^{-4}$
3	$\geq 10^{-4}$ to $< 10^{-3}$
2	$\geq 10^{-3}$ to $< 10^{-2}$
1	$\geq 10^{-2}$ to $< 10^{-1}$

<sup>1</sup> Electrical/electronic/programmable electronic systems


Table 2. Probability of a Dangerous Failure Per Hour (High Demand System)

Safety Integrity Level	High demand or continuous mode of operation (Probability of a dangerous failure per hour (PFH))
4	$\geq 10^{-9}$ to $< 10^{-8}$
3	$\geq 10^{-8}$ to $< 10^{-7}$
2	$\geq 10^{-7}$ to $< 10^{-6}$
1	$\geq 10^{-6}$ to $< 10^{-5}$

**NOTE:**

The XNX system is Type B. A Type B system uses controllers or programmable logic per IEC 61508.

The XNX product consists of a main board, a personality board, and a sensor.



\* **Note:** Only one personality board per XNX main board

This manual outlines the proof test procedure, a required operation to maintain the XNX’s functional safety under low demand applications.

## 3 Safety Parameters

The safety parameters listed below are a combination of the main board, personality board, and sensor. These numbers were provided by TUV in report 968/EL 665.01/09 (personality boards) and report 968/EZ 319.02/09 (main board). For safety parameters of the individual sensors, refer to the *XNX Safety Parameters For Sensors* white paper.

Component	SIL Level*	Safety Architecture	PFDavg**	PFH (1/h)	SFF %	DC %	Test Report
XNX Universal Transmitter with Combustible Sensor (IR board)	SIL2	1oo1	2.7E-04	6.2E-08	96.6	>90%	TUV 968/EZ 319.05/15 TUV 968/EL 665.01/09
	$\lambda$ (fit)	$\lambda_{Du}$ (fit)	$\lambda_{Dd}$ (fit)	$\lambda_D$ (fit)	SC	PTC %	
	3611	122	733	855	2	100	

Component	SIL Level*	Safety Architecture	PFDavg**	PFH (1/h)	SFF %	DC %	Test Report
XNX Universal Transmitter with Combustible Sensor (mv Catalytic bead) Sensepoint and Sensepoint HT detector	SIL2	1oo1	4.8E-04	1.1E-07	94.8	>90%	TUV 968/EZ 319.05/15 TUV 968/EL 665.01/09
	$\lambda$ (fit)	$\lambda_{Du}$ (fit)	$\lambda_{Dd}$ (fit)	$\lambda_D$ (fit)	SC	PTC %	
	4245	222	1013	1235	2	100	

Component	SIL Level*	Safety Architecture	PFDavg**	PFH (1/h)	SFF %	DC %	Test Report
XNX Universal Transmitter with Toxic Sensor	SIL2	1oo1	2.5E-04	5.7E-08	96.8	>90%	TUV 968/EZ 319.05/15 --
	$\lambda$ (fit)	$\lambda_{Du}$ (fit)	$\lambda_{Dd}$ (fit)	$\lambda_D$ (fit)	SC	PTC %	
	3569	114	720	834	2	100	

Component	SIL Level*	Safety Architecture	PFDavg**	PFH (1/h)	SFF %	DC %	Test Report
XNX Universal Transmitter with Oxygen Sensor	SIL2	1oo1	2.5E-04	5.7E-08	96.8	>90%	TUV 968/EZ 319.05/15 TUV 968/EZ 493.00/11
	$\lambda$ (fit)	$\lambda_{Du}$ (fit)	$\lambda_{Dd}$ (fit)	$\lambda_D$ (fit)	SC	PTC %	
	3569	114	720	834	2	100	

*continued...*

Component	SIL Level*	Safety Architecture	PFDavg**	PFH (1/h)	SFF %	DC %	Test Report
XNX Universal Transmitter with Infrared Combustible Gas Detector (with Searchpoint Optima Plus)	SIL2	1oo1	4.8E-04	1.1E-07	95.9	>81%	TUV 968/EZ 319.05/15 TUV 968/EZ 559.00/12
	$\lambda$ (fit)	$\lambda_{Du}$ (fit)	$\lambda_{Dd}$ (fit)	$\lambda_D$ (fit)	SC	PTC %	
	5375	220	2265	2486	2	100	

Component	SIL Level*	Safety Architecture	PFDavg**	PFH (1/h)	SFF %	DC %	Test Report
XNX Universal Transmitter with Infrared Combustible Gas Detector (with Searchline Excel)	SIL2	1oo1	7.7E-04	1.8E-07	95	--	TUV 968/EZ 319.05/15 Exida 04/08-13 R001
	$\lambda$ (fit)	$\lambda_{Du}$ (fit)	$\lambda_{Dd}$ (fit)	$\lambda_D$ (fit)	SC	PTC %	
	5445	269	2005	2275	2	100	

Component	SIL Level*	Safety Architecture	PFDavg**	PFH (1/h)	SFF %	DC %	Test Report
XNX Universal Transmitter Standalone XNX Transmitter (main board)	SIL2	1oo1	1.2E-04	2.8E-08	98.2	>90%	TUV 968/EZ 319.05/15
	$\lambda$ (fit)	$\lambda_{Du}$ (fit)	$\lambda_{Dd}$ (fit)	$\lambda_D$ (fit)	SC	PTC %	
	3155	55.6	633	689	2	100	

\*This rating is highest achievable SIL level the XNX, Searchpoint Optima Plus gas detection system can achieve as standalone safety devices. In more complex safety system the above values are the safety parameters of XNX and Optima gas detection system required to determine the acceptance of the complete safety function (i.e., all safety parameters, safety architecture, etc.) as required by IEC 61508 and IEC 61511.

\*\*Denotes a proof test interval of one year.

## 3.1 Interval of Proof Testing

If the XNX is used in high demand systems, a proof test is not required. If the XNX is used in low demand systems (defined as 1 demand or less per year) a proof test is required. Perform the proof test once a year to comply with IEC 61508.

Section 6 Proof Testing Procedure outlines the actions that must be completed for a proof test.

## 4 Fault Diagnostic Time Interval

XNX conducts approximately 30 diagnostics total on the main board and personality board. These diagnostics occur at different time intervals, with the longest interval at 24 hours. But when a fault is detected, it is reported within 3 seconds. Refer to the XNX Technical Manual for more information on diagnostics.

## 5 Proof Test

### 5.1 Purpose of Proof Testing

A proof test is a periodic test to detect failures in the system so that, if necessary, the system can be restored to an “as new” condition or as close as practical to this condition.

### 5.2 Expected Outcome of Proof Testing

The following features are checked and adjusted if required

- current output at different levels (4.0 mA and 20.0 mA)
- verifying zero gas and span gas calibration current output
- verifying current output of warnings and faults
- simulating warnings and faults
- validation of the current output of zero gas and/or span gas calibration (required if the current output of zero gas and/or span gas calibration had to be changed)

### 5.3 Tolerance of Output Current Levels

The tolerance for the output current levels is  $\pm 0.1$  mA.

Example: If the procedure requires the current output to be 4.0 mA, the actual current reading at the controller end can range from 3.9 mA to 4.1 mA.

## 6 Proof Testing Procedure

### 6.1 Checking

The purpose of checking is to ensure the mA output meets the expected levels. If the current does not meet the expected levels, it will have to be adjusted. If, after completing [6.1.1](#), [6.1.2](#), and [6.1.3](#), the mA output does meet the expected levels, proceed to [6.3](#).

#### 6.1.1 Force mA Output

1. Ensure the current can be measured at the controller end. The current will be measured using the procedures outlined in [6.1.1](#) to [6.1.3](#).
2. From the Main Menu, select the Test Menu (🔧).



#### CAUTION

The mA output set in this menu will revert to the normal operating values when exiting the Test Menu. For more information on setting the mA output levels for normal operation, see mA Levels in the XNX Technical Manual.

3. From the Test Menu, select Force mA Output (🔧).

The New mA Output screen shows the existing mA output in the left column. The user can adjust the output by changing the value in the column on the right.




Figure 1. New mA Output Screen

4. Ensure the current at the controller end is 4.0 mA. If the current is not 4.0 mA, refer to [6.2.1](#) to adjust the output.
5. Repeat steps #2-4 to check the output of 20.0 mA.

## 6.1.2 Zero Gas mA Output

The procedure for zero gas is not applicable to the ECC O<sub>2</sub> sensor.

1. Apply zero gas to the sensor.
2. The current at the controller end should be 4.0 mA.

If the mA output is not at the expected level when applying zero gas, perform a Zero Gas Calibration. Refer to [6.2.2](#) and complete the procedure for a Zero Gas Calibration.

## 6.1.3 Calibration Gas mA Output

1. Apply calibration gas to the sensor.
2. The current measured at the controller end is related to the percentage of gas applied.

Example: 100% of full gas concentration is equivalent to 20.0 mA. If 75% of the full scale gas concentration is applied, the mA output should be 16.0 mA.

If the mA output is not at the expected level when applying calibration gas, refer to [6.2.2](#) and perform a Zero Gas Calibration and a Span Gas Calibration.

## 6.2 Adjusting

Perform the following procedures if 4.0 mA and 20.0 mA were not measured at the controller end. If the correct currents were measured, proceed to [6.3](#).

The current must be measured at the controller end in [6.2.1](#) and [6.2.2](#).

### 6.2.1 Calibrate 4.0 mA and 20.0 mA

1. From the Main Menu, select the Test Menu (🔧).
2. Then select Force mA output (🔧).
3. Adjust the current output in the column on the right until the current at the controller end is 4.0 mA.




Figure 2. Adjusting Current

4. Once the new value is entered, use the  $\leftarrow$   $\rightarrow$  switches to move to the '✓' and select  $\checkmark$  to set the mA output.

If the 20.0 mA output was not equal to 20.0 mA, complete steps #3-4.

### 6.2.2 Zero Gas Calibration and Span Calibration

The following section outlines the steps for calibrating the attached XNX sensors. For calibration information for specific sensors, refer to the XNX Technical Manual.

1. If using a compressed gas cylinder, push the calibration gas flow housing onto the bottom of the sensor and apply the gas.
2. Access the Calibration Menu.



Figure 3. Gas Calibration Menu

#### NOTE:

The Gas Calibration Menu is for both Zero Gas and Span Gas Calibration.



## 6.2.2.1 Zero Gas Calibration



Figure 4. Zero Gas Calibration Screen

As the sensor detects the zero gas and the concentration increases, the values displayed will reflect the changing concentration. When the concentration values are stable select  to allow the XNX to calculate the zero adjustment. Selecting  will return to the Gas Calibration Menu.



Figure 5. Zero Gas Calibration in Progress

3. If the Zero Gas Calibration is successful, the Zero Passed screen displays.




Figure 6. Zero Gas Calibration Passed

## 6.2.2.2 Span Calibration

### NOTE:

If a Span Calibration is not required, select  to skip the Span Calibration and return to the Calibration Menu.

1. When the Zero Gas Calibration is complete, the Span Concentration screen appears. The gas concentration for the Span Gas Calibration can be changed. If the Span Calibration is skipped, the Gas Calibration screen displays.




Figure 7. Span Gas Concentration Screen

2. Enter the concentration of the span gas by selecting  to choose the first digit and use the   switches to increment or decrement the values. Use  to accept the new value and move to the next digit. Continue until all digits have been selected.




Figure 8. Span Calibration Screen

3. Apply the span gas. As the sensor detects the gas and the concentration increases, the values displayed will reflect the changing concentration. When the concentration values are stable select  to perform the span. The Span Calibration process also determines whether the sensor is within the proper range to accurately detect the target gas.

Selecting will cancel the span calibration and return to the Gas Calibration Menu.

- When the sensor has completed the calibration and the span algorithms have determined that it is within range, the Span Passed screen will appear.




Figure 9. Span Passed Screen

If the calibration is not successful, the Span Failed screen will display. Selecting will return to the Span Concentration screen to begin the span calibration again. Selecting will exit Span Calibration and return to the Gas Calibration Menu.




Figure 10. Span Calibration Failed

Once the Zero Gas and Span Gas calibrations are completed successfully, the user will be prompted to

- exit with inhibit off,
- exit with inhibit on, or
- not exit.



Figure 11. Exiting Zero Gas and Span Gas calibrations

## WARNING

While XNX is in Inhibit Mode, alarms are silenced. This will prevent an actual gas event from being reported. Inhibit Mode must be reset after testing or maintenance activities.

## 6.3 Verifying mA Settings

The mA levels output for inhibiting alarms during maintenance/testing, warnings triggered by the XNX, overrange conditions, Beam Blocked and Low Signal for the Searchpoint Optima Plus and Searchline Excel gas detectors must be verified.

- From the Main Menu, select the Configure Menu (). From the Configure Menu, select mA Levels.



Figure 12. mA Levels Menu

- Use the switches to move to the mA output to be changed and use to select it.



Figure 13. Set mA Levels for Warning

- Refer to Table 6 for the mA levels. If the values do not match the values in the table, proceed to step #4 to adjust the values.

## NOTE

If the values for the faults and warnings have been changed from the default settings since installation, ensure the current output matches those changed values.

Table 3. Set mA Levels

Signal*		Output (mA)		
		Default	Min	Max
I	Inhibit	2.0 mA	1.0	3.5
W	Warning	3.0 mA	1.0	3.5
O	Overrange	21.0 mA	20	22
B**	Beam Blocked	1.0 mA	1.0	4.0
L**	Low Signal	1.0 mA	1.0	4.0
*Faults are set to 1 mA and are not user-selectable				
**Beam blocked and Low Signal apply only to Excel sensors.				

- Using the ◀▶ switches, increment or decrement the value until the desired value appears. Then use ✓ to confirm the value and move to the next setting. Repeat for each setting that must be changed.

The available output range for Inhibit, Warning, Beam Blocked and Low Signal is from 1.0 to 4.0 mA and for an overrange condition, the range is 20.0 to 22.0 mA. Refer to Section 5 Warnings/Faults in the XNX Technical Manual for more information.

- Once all changes have been made, use the ◀▶ switches to move to the ✓ and use ✓ on the front panel to save the settings.



Figure 14. mA Settings Saved

## NOTE:

If '✓' is not selected, none of the changes will be saved.

## 6.4 Testing

### 6.4.1 Fault and Alarm State

The mA output of the faults and alarm states should be simulated and the current output at the controller end should be within tolerance. Refer to Table 6 for the current values for the fault and alarm states.

- From the Test Menu, select Alarm/Fault Simulation.



Figure 15. Alarm/Fault Simulation Screen

- Figure 16 shows the menu choices simulating Alarm 1, Alarm 2, Warning, or a Fault. Selecting the return arrow icon will display the Alarms/Fault Reset Menu.



Figure 16. Alarm/Fault Simulation Menu

- Selecting an alarm level to simulate will activate a confirmation screen.




Figure 17. Confirmation

Selecting  will simulate the selected alarm. If the  is selected, the simulation is aborted.

- To simulate a Warning or Fault from the XNX, select the appropriate icon from the menu.




Figure 18. Warning and Fault Simulation Screens

- As in an alarm simulation, a confirmation screen will appear. Selecting  will simulate a warning or fault from the XNX. If  is selected, the simulation is aborted.




Figure 19. Fault Simulation Confirmation

- Use Alarm/Fault Reset to reset alarms, faults or warnings generated by the simulation.




Figure 20. Alarm/Fault Reset Screen

As in an alarm simulation, a confirmation screen will appear.



Figure 21. Alarm/Fault Reset Confirmation Screen

Selecting  will reset all alarms, faults or warnings generated by the simulation. If  is selected, the simulation continues.

## CAUTION

The alarms and faults generated by the simulation will not be cleared from the XNX until alarms/faults are reset. Failure to reset the alarms/faults upon exiting the simulation keeps the relays and LEDs in alarm/fault mode.

### 6.4.2 Gas Verification

To verify the mA output of Zero Gas and Calibration, refer to [6.1.2](#) and [6.1.3](#).

A different bottle of calibration gas and/or zero gas should be used to verify the results.

**Learn more:**

[www.honeywellanalytics.com](http://www.honeywellanalytics.com)

**Americas**

Honeywell Analytics  
405 Barclay Boulevard  
Lincolnshire, Illinois 60069  
Tel: +1 847 955 8200  
Toll free: +1 800 538 0363  
Fax: +1 847 955 8210

[detectgas@honeywell.com](mailto:detectgas@honeywell.com)

**Europe, Middle East, and Africa**

Life Safety Distribution GmbH  
Javastrasse 2, 8604 Hegnau  
Switzerland

Main Phone: +41 (0)44 943 4300

Main Fax: +41 (0)44 943 4398

[gasdetection@honeywell.com](mailto:gasdetection@honeywell.com)

**Asia Pacific**

Honeywell Industrial Safety  
7F SangAm IT Tower  
434, Worldcup Buk-ro, Mapo-gu  
Seoul 03922

Korea

Tel: +82 (0) 2 6909 0300

Fax: +82 (0) 2025 0329

[analytics.ap@honeywell.com](mailto:analytics.ap@honeywell.com)

**Technical Services**

[ha.global.service@honeywell.com](mailto:ha.global.service@honeywell.com)

[www.honeywell.com](http://www.honeywell.com)

**Please Note:**

While every effort has been made to ensure accuracy in this publication, no responsibility can be accepted for errors or omissions.

Data may change, as well as legislation, and you are strongly advised to obtain copies of the most recently issued regulations, standards and guidelines.

This publication is not intended to form the basis of a contract.

1998-0808

Revision 3

November 2016

© 2016 Honeywell Analytics

**Honeywell**

